



SNAP FIT TONNEAU COVER

Please read the following instructions carefully before commencing installation.

PARTS INCLUDED:

- > Corner brackets x 4
- > Aluminium side rails x 2
- > Front aluminium rails x 1
- > Tonneau cover x 1
- > Rear aluminium rail x 1
- > Aluminium bows x 2
- > Mounting brackets x 4
- > Allen key 3/16 x 1
- > Fastener bases

TYPICAL INSTALLATION TIME: approximately 40 minutes.



STEP 1: Slide tonneau cover front extrusion onto front rail.



STEP 2: Slide fasteners onto rear and side rails as required.



STEP 3: Lay all rails on top lip of well-side and snap corners into place.



STEP 4: Position clamps on side rails with three even spaces. Fasten clamps onto side rails and tighten with 3/16 allen key provided.



STEP 6: Stretch and snap cover into place to achieve the best fit.



NOTE: The cover can be conveniently stored when it's not required. Simply remove the rear rail and corners and roll the cover forward. Velcro straps hold it neatly in place.

STEP 5: Place cross bows into brackets. These are spring-loaded on one side for easy installation.