



## SNAP FIT TONNEAU COVER WITH SPORTS BAR

Please read the following instructions carefully before commencing installation.

### PARTS INCLUDED:

- > Corner brackets x 4
- > Aluminium side rails x 2
- > Front aluminium rails x 1
- > Tonneau cover x 1
- > Rear aluminium rail x 1
- > Aluminium bows x 2
- > Mounting brackets x 4
- > Allen key 3/16 x 1
- > Fastener bases
- > Extender plates x 4
- > M8 cap screws
- > Springwashers x 8

**TYPICAL INSTALLATION TIME:** approximately 40 minutes.



**STEP 1:** Remove sports bar, taking care to safely store mounting bolts for later use.



**STEP 2:** Bolt sports bar extender plates to the sports bar using M8 cap screws and spring washers.



**STEP 3:** Slide tonneau cover front extrusion onto front rail.



**STEP 4:** Slide fasteners onto rear and side rails as required.



**STEP 5:** Lay all rails on top lip of well-side and snap corners into place.



**STEP 4:** Position clamps on side rails with three even spaces. Fasten clamps onto side rails and tighten with 3/16 allen key provided.



**STEP 6:** Stretch and snap cover into place to achieve the best fit.



**STEP 5:** Place cross bows into brackets. These are spring-loaded on one side for easy installation.

**NOTE:** The cover can be conveniently stored when it's not required. Simply remove the rear rail and corners and roll the cover forward. Velcro straps hold it neatly in place.